



راهنمای نصب

# PMG5617-T20B2



## فهرست مطالب

<u>جراغ های ONT</u> تنظیمات ONT از طریق Wizard تنظیمات از طریق PPPOE تنظیمات وایرلس <u>IP تنظیمات Port forwarding</u> تنظیمات ACL تنظیمات Voip تنظیمات ONT

این ONT مخصوص سرویس FTTH است و کابل فیبر نوری به آن متصل می شود.

 ZYXEL communications Garperation

 Model Number: PMGE60772002
 Power Roting: SZYZENA

 Dindscowers: TXX 2: 01, X660 Secorg, Dennorski
 Dindscowers: TXX 2: 01, X660 Secorg, Dennorski

 Dindscowers: TXX 2: 01, X660 Secorg, Dennorski
 Dindscowers: TXX 2: 01, X660 Secorg, Dennorski

 Dindscowers: TXX 2: 01, X660 Secorg, Dennorski
 Dindscowers: TXX 2: 01, X660 Secorg, Dennorski

 Dindscowers: TXX 2: 01, X660 Secorg, Dennorski
 Dindscowers: TXX 2: 01, X660 Secorg, Dennorski

 Dindscowers: TXX 2: 01, X660 Secorg, Dennorski
 Dindscowers: TXX 2: 01, X660 Secorg, Dennorski

 Dindscowers: TXX 2: 01, X660 Secorg, Dennorski
 Dindscowers: TXX 2: 01, X660 Secorg, Dennorski

 Dindscowers: TXX 2: 01, X660 Secorg, Dennorski
 Dindscowers: TXX 2: 01, X660 Secorg, Dennorski

 Dindscowers: TXX 2: 01, X660 Secorg, Dennorski
 Dindscowers: TXX 2: 01, X660 Secorg, Dennorski

 Dindscowers: TXX 2: 01, X660 Secorg, Dennorski
 Dindscowers: TXX 2: 01, X660 Secorg, Dennorski

 Dindscowers: TXX 2: 01, X660 Secorg, Dennorski
 Dindscowers: TXX 2: 01, X660 Secorg, Dennorski

 Dindscowers: TXX 2: 01, X660 Secorg, Dennorski
 Dindscowers: TXX 2: 01, X660 Secorg, Dennorski

 Dindscowers: TXX 2: 01, X660 Secorg, Dennorski
 Dindscowers: TXX 2: 01, X660 Secorg, Dennorski

 Dindscowers: TXX 2: 01, X660 Secorg, Dennorski
 Dindscowers: TXX 2: 01, X660 Secorg, Dennorski

Username و password ورود به کنسول مودم بر روی برچسبی که در زیر ONT قرار دارد درج شده است.

#### چراغ های ONT :

چراغ GPON بیانگر اتصال فیبر و چراغ Internet نشانگر اتصال PPPoE است.



تصویر پشت ONT:



اتصال فیبر از طریق سوکتی که زیر ONT قرار دارد انجام میشود مطابق شکل زیر:



منوهای اصلیONT مطابق شکل زیر است.



تنظيمات ONT از طريق Wizard:

	Login	
User Name		-
Password		0
	Levela	

این مرحله مربوط به تغییر پسورد ورود به کنسول ONT است.

	Pus:	sword	Rese	1	
New P	assword				
					$^{\odot}$
Precourt	and				
1 (4334) 4	ла				0
lhe pas charac	sword mu tor and or	st contain 19 alphanu	at least o Imotic ch	ne numer aracter.	ic
	Cha	nge pa	Issword	1	
		Skip			

Quick Start Wizard							
1 Time Zone	> (2) Internet	> (3) WiFi					
The wizard will guide This will t	you through the basi ake a few minutes to <b>Let's ao</b>	c settings of this device. complete.					
	Skip						

1 > Time zone	2 Internet	> (3) WiFi
Time Zone		
(GMT+01:0	0) Amsterdar	n, Berlin ▼
Back	s N	ext



در این قسمت تنظیمات وایرلس مربوط به دو فرکانس نمایش داده شده را انجام دهید:

EL MG561	/12082					
		<b>D</b> Time zone	>	internet >	3 WIFI	
	2.4G WiFi	0			5G WIFI	
WIFI Name				WIFI Name		
Zyxel_49C1				Zyxel_49C1_	_5G	
WIFI Password				WIFI Password		
********			0	*******		0

منوی connection status در صفحه اصلی اطلاعات کلی را به شما نمایش میدهد:

Conne	ctivity			System	Info			
	•		)	Model Nan Remissing V System Upt LAH MAC J WAN Storu	re PM0 wiston V5, ime 0.de Address SC: c Cor	35617(2082 11 (ACB8.0)63a01 1ys 0 hours 50 minutes 34 54:8E:77:49:C0 inection down	econds	>
WiFi Se	ttings			Guest	WiFi Settings			
() 2.40	2.4G WIFI Name	WIFI Postward		() 2.60	2.4G WIR Nome	WIF) Password		
-	Zyxel_49C1	•••••	0		Zyxel_49C1_quest1		0	
	SC WH Name Zyxel_49C1_5G	WH Passued	©	ŝ,	SC WH Nome Zyxel_49C1_guest1	_5G •••••	0	~
LAN								/
E Andros	109.14							
Subnet Mr	255.25	5.255.0						

### تنظيمات ONT به صورت Manual :

\_\_\_\_\_

### تنظيمات PPPOE:

	Connection Status	×
	Network Setting	
System Info	Broadband	Wizard
	Wireless	
Model Name	Home Networking	
Firmware Version	Routing	Theme
System Uptime	NAT	(h)
	DNS	$\bigcirc$
LAN MAC Address	Vlan Group	Restart
WAN Status	Interface Grouping	
	USB Service	Language
Guest WiFi Set	Security	(B)
	VoIP	Logout
2.4G Zyxel_49C	Activate Win System Monitor Settings to	dows activate Windows.

در صفحه اصلی ONT به قسمت Network setting بروید و روی گزینه Broadband کلیک کنید .سطر اول را برای تغییرات انتخاب کنید و تنظیمات را به صورت زیر انجام دهید:

#### Broadband

Use this screen to change your Zyxel Device's Internet access settings. The summary table shows you the configured WAN services (connections) on the Zyxel Device. Use information provided by your ISP to configure WAN settings.

#	Name	Туре	Mode	Encapsulation	802.1p	802.1q	IGMP Proxy	NAT	Default Gateway	IPv6	MLD Proxy	Modify
1	WANT	PON	Routing	IPoE	1	4010	Y	Ŷ	Y	N	N	ß
2	WAN2	PON	Routing	IPoE	N/A	N/A	N	Y	N	Ν	N	Ø
3	WAN3	PON	Routing	IPoE	N/A	N/A	N	Y	N	Ν	Ν	Ø
4	WAN4	PON	Routing	IPoE	N/A	N/A	N	Y	N	Ν	Ν	Ø
5	WAN5	PON	Routing	IPoE	N/A	N/A	N	Y	N	N	Ν	Ø
6	WAN6	PON	Routing	IPoE	N/A	N/A	N	Y	N	Ν	N	Ø
7	WAN7	PON	Routing	IPoE	N/A	N/A	N	Y	N	N	N	Ø
8	WAN8	PON	Routing	IPOE	N/A	N/A	N	Y	N	N	N	Ø



MVLAN	2850 © MTU	(1~4094)	Obtain DNS Info Automatically     Use Following Static DNS Address
MTU	1492 ©		
NAT Apply as Defa Gateway	IGMP Prox	y D	
	6RD	Cancel	Apply

تنظيمات وايرلس:

در قسمت Network setting بر روی گزینه Wireless کلیک کنید و تنظیمات را به صورت زیر انجام دهید:

Use this screen to enable the Wireless L4	AN, enter the SSID and select the wireless security mode. We recommend the security mode.	nat you select More Secure to enable WFA2-FSK data encryption.
freless Network Setup		
Band	2.4GHz	300
Wireless	<b>C</b>	
Channel	Auto	♥ Current: 4 / 20 MHz
Bandwidth	20MHz	*
Control Sideband	None	
ireless Network Settings		
Wretess Network, Name	Zyxel_49C1	
Max Clients	32	
Hide SSID		
Multicast Forwarding		
Max Upstream Bandwidth		Kops
		Khor

	No Security	More Secure (Recommended)	
		•	
Security Mode	WPA2-PSK	<b>2</b>	
Generate password a	utomotically		
Enter 8-63 ASCII characte	rs or 64 hexadecimal digits ("D-9", "A-F").		
Password	*********	0	
Strength	medium		
¥-			

از طریق منوی Mac authentication میتوانید مکهای مورد نظر را در لیست اضافه کنید:

	Wireless	
General Guest/More AP	MAC Authentication WPS WMM Others Channel Sta	105
Use this screen to give exc <b>Deny</b> ) based on the MAC assigned at the factory ar MAC addresses of the dev	lusive access to specific devices ( <b>Allow</b> ) or exclude specific address of each device. Every Ethernet device has a unique id consists of six pairs of hexadecimal characters, for exampl rice(s) you want to allow/deny to configure this screen.	devices from accessing the Zyxel Device ( MAC (Media Access Control) address. It is e, 00:A0:C5:00:00:02. You need to know the
General		
SSID	Zyxel_49C1 -	
MAC Restrict Mode	🖲 Disable 🔿 Deny 🚫 Allow	
MAC address List		
		HAdd new MAC addres
#	MAC Address	Modify
	Cancel Apply	Activate Wind Go to Settings to a

تنظیمات WPS را میتوانید از طریق تب wps در قسمت Wireless مطابق تصویر زیر انجام دهید:

Wireless								
eneral	Guest/More AP	MAC Authenti	cation WPS	WMM	Others	Channel Status		
ViFi Protected nethods and f rour device su	Setup (WPS) allows you t follow the instructions to e pports it.	o quickly set up a wirel establish a WPS connec	ess network with strong : tion. Your device must s	security, witho support WPS to	out having to c o use this featu	onfigure security settings ire. We recommend using	manually. Select one Push Button Configu	e of the WPS uration ( <b>PBC</b> ) if
neral /PS Id a new de	evice with WPS Meth	<b>C</b>						
Meth Step 1. Click ' Step 2. Press t client	od 1 PBC ( WPS button the WPS button on your n device within 120 secon	WPS ew wireless ds	Step1. Enter the PIN of device and the Step2. Press the WPS bi	your new wire n click Registe utton on your	eless client er Register new wireless	Enter AP's PIN M Current state C 1. Please relea configure th Release Co	umber in wireless Cli onfigured se configuration if yo a wireless settings nfiguration	<b>ient</b> ou want to
e			client device wi	ithin 120 seco	nds	2. Enter curren Generate 1	PIN number on your	r wireless client

كانال وايرلس نيز از طريق صفحه زير قابل تغيير است:

		Wireless		
General Guest/Mo	e AP MAC Authentication	WPS WMM Others	Channel Status	
Use this screen to scan for section. The value on ec does not always directly	r wireless LAN channel noise and vi ch channel number indicates the n follow the AP count; other factors c	iew the results. Click <b>Scan</b> to star umber of Access Paints (AP) usin about the channels are also con-	t, and then view the results in th ng that channel. The Auto-chan sidered.	e Channel Scan Result nel-selection algorithm
Chann <mark>el Monitor</mark>				
Scan wireless LAN Channel	Sean			
Note				
<ol> <li>It takes about 15 second</li> </ol>	is to scan the wireless channels			
Channel Scan Result				
Time for last scan: N/A				
Note				

۲۲ ]-

### تنظيمات IP:

LAN Setup Static DHCP UPnP	Additional Sub	net Wake on	LAN IFTP Ser	verNome Loop	Guard
Use this screen to set the Local Area Network IP a	ddress and subnet mask	of your Zyxel Device. C	Configure DHCP setting	s to have the Zyxel Device	e or a DHCP server assign IP addr
interface Group					
Group Name	Default				•
LAN IP Setup					
IP Address	192	168	1	Ť	
Subnet Mask	255	255	255	0	
DHCP Server State					
DHCP	🧿 Enable 🔘 Disable	O DHCP Relay			
P Addressing Values					
Beginning IP Address	192 .	168	τ.	2	
Endina IP Address	192	168	Ť	254	
Auto reserve IP for the same host					
DHCP Server Lease Time					
1 doys	0	hours	0	minutes	
DNS Values					
DNS	🖲 DNS Proxy 🔘 Stat	ic () From ISP			
AN IPv& Mode Setup					
IPv6 Active					

برای تنظیمات آی پی میتوانید از طریق منوی Networksetting بر روی گزینه Home networking کلیک کنید.

#### تنظيمات Port forwarding :

در قسمت Networksetting بر روی گزینه NAT کلیک کنید تا وارد تنظیمات Portforwarding شوید:

to forward incom	ing service rea	quests from th	e Internet	t to the e	11631			
	ost online gam	ning, P2P file st	haring, or	other se	erver(s) on your rvers on your ne	local networ <mark>k.</mark> F twork.	ort forward	ing is
							+ Add	New Rule
Originating IP	WAN Interface	Server IP Address	Start Port	End Port	Translation Start Port	Translation End Port	Protocol	Modify
	Originating IP	Originating WAN IP Interface	Originating WAN Server IP IP Interface Address	Originating WAN Server IP Start IP Interface Address Port	Originating WAN Server IP Start End IP Interface Address Port Port	Originating WAN Server IP Start End Translation IP Interface Address Port Port Start Port	Originating WAN Server IP Start End Translation Translation IP Interface Address Port Port Start Port End Port	Originating WAN Server IP Start End Translation Translation IP Interface Address Port Port Start Port End Port Protocol

با کلیک بر روی گزینه Add New Rule میتوانید تنظیمات مورد نظر را در این قسمت انجام دهید:

	Add New Rule
Active	
Service Name	
WAN Interface	Default -
Start Port	
End Port	
Translation Start Port	
Translation End Port	
Server IP Address	
Configure Originating IP	Enable
Protocol	TCP ·
ote	

1.To configure port forwarding, you need to have the same configurations in the Start Port, End Port, Translation Start Port, and Translation End Port fields.

To configure port translation, you need to have different configurations in the Start Port, End Port, Translation Start Port, and Translation End Port fields.

Here's an example to configure port translation. Configure Start Port to 100, End Port to 120, Translation Start Port to 200, and Translation End Port to 220.

2.TCP port 7547 is reserved for system use.

Cancel OK

تنظيمات ACL:



از طریق منوی Maintenance با کلیک بر روی گزینه Remote Management امکان دسترسی به کنسول ONT وجود دارد.

GMT Services	Trust Do <mark>m</mark> ain			
Use this screen to configu the Zyxel Device.	re through which interface(	s), each service can access the Zyxel Devic	e. You can also specify service port nu	mbers computers must use to connect to
rvice Control				
VAN Interface used for se	rvices	● Any_WAN ◯ Multi_WAN		
		WANI WANZ WAN	3 🗰 WAN4 🔛 WAN5 🔛 V	NAN6 WAN7 WAN8
Service	LAN/WLAN	WAN	Trust Domain	Port
HTTP	Z Enable	Enable		80
HTTPS	C Enable	Enable	Enable	443
FTP	Menable	Enable	Enable	21
TELNET	🛃 Enable	🗌 Enable	Enable	23
SSH	🛃 Enable	Enable	Enable	22
SNMP	🛃 Enable	Enable	Enable	161
-	Fnable	Enoble	Enable	

#### تنظيمات Voip :

از طریق منوی Voip گزینه SIP را انتخاب کنید.

SIP Account	D Son doo Droudd				
	IF SERVICE FROVID	er			
You can mak provider.	e calls over the li	nternet using VoIP tea	chnology. For this, you first need t	o set up a SIP account with a SIP	service
The Zyxel Dev SIP account's a phone port	ice uses a SIP ac VoIP number. In The SIP accoun	count to make outgo order to make or rec t contains informatior	ping VoIP calls and check if an ine eeive a VoIP call, you need to en In that allows your Zyxel Device to	coming call's destination number able and configure a SIP accoun connect to your VoIP service pro	r matches your It and map it to ovider.
				+	Add New Account
# En	able	SIP Account	Service Provider	Account Number	Modify
1 Disc	abled	SIP 1	ChangeMe	ChangeMe	ß

با کلیک بر روی گزینه Add New Account وارد صفحه زیر خواهید شد:

	SIP Account Selection Change	Ле	
	SIP Service Provider Association		
	SIP Account Associated with	voice.shatel.ir	•
	General		
	Z Enable SIP Account	شماره شاتل تاک به همراه	
	SIP Account Number	كد شهر بدون صفر 219100	
	Authentication		
	Username	شماره شاتل تاک به همراه کد شهر بدون صفر	
	Password	پسورد شاتل تاک	
	URL Type	$\smile$	
	URL Type	SIP	•
	Voice Features		
	Primary Compression Type	G.711u	
	Secondary Compression Type	G.711a	•
	Third Compression Type	G.722	1
	Speaking Volume Control	Middle	-
1	Password URL Type URL Type Voice Features Primary Compression Type Secondary Compression Type Third Compression Type Speaking Volume Control	********* SIP G.711u G.711a G.722 Middle	• • • •

			۰	OIP Status			
Informatio page.	n, such as wh	ether a SIP accou	unt is registered a	and the total call volume made	by a SIP acco	unt, can be viewe	ed in the
Poll ntervial(s)	10		ŝ	SIOC		S <mark>et.</mark>	nterval Stop
SIP Statu: Account	s Register Action	Registration	Registration Time	URI	Message Waiting	Last Incoming Number	Last Outgoing Number
1		Registered	0 day(s), 01:15:32	21910	No	09122	0912
2		Disabled		ChangeMe@voice.shatel.ir	No		

			Phone		
hone	Device Region	n.			
Pho spe mak	ne Device configu cific SIP account r te an outgoing cal	ration defines the relations b number receive an incoming o l.	etween your SIP account(s) and pho call; and which SIP account number	ne(s). That is, which phone(s) will r will be used when a specific phone	ing when a is used to
nalo	og Phone				
#	Phone ID	Internal Number	Incoming SIP Number	Outgoing SIP Number	Modify
#	Phone ID PHONE1	Internal Number	2191	Outgoing SIP Number	Modify

Call Histo	ry page shows	the inform	ation of prev	rious call.				
Classify::	All			( <b>*</b> )		Cle	ar List Refresh	Export
						😵 Incoming	Coutgoing	e Missed
Туре	1	Date	Name	Number	Phone Device	Outgoing Number	Duration (hh:mm:ss)	Modify
C	12-3 14	28-2021 :36:25		00122 0107	PHONE1	21910	00:00:00	Û
S	12-2 14	28-2021 :36:14		0912	PHONE1	21910	00:00:00	Û
C.	12-2 14	28-2021 :32:50		09122	PHONE1	219102008	00:00:01	đ
S.	12-3 14	8-2021 29:21		091225	PHONE1	21940	00:00:11	8
C.	12-2 20	26-2021 :48:08		7734		219109	00:00:00	đ
C	12-2 20	26-2021 :46:53		77540-00		21910	00:00:00	0
	12-2	26-2021		666		21910	00:00:00	8

به روز رسانی ONT:

	Firmware Upgrade	
This screen lets you upload new firmware to your Zyxel	Device.	
Download the latest firmware file from the Zyxel websit (Hypertext Transfer Protocol) and may take up to two r	e and upload it to your Zyxel Device using minutes. After a successful upload, the Zyx	g this screen. The upload process uses HTTP kel Device will reboot.
Upgrade Firmware		
Restore Default Settings After Firmware Upgrade		
Current Firmware Version: V5.41 (ACBB.0)b3a01		
File Path	Choose File No file chosen	Upload

٢٢

\_\_\_\_\_